




120 mm Fan Duct Installation guide


(Pic. 1)



(Pic. 2)




(Pic. 3)



(Pic. 4)

(Pic. 5)



Fan Duct Installation for HR-01

1. Attach the system fan (of size 12cm, pic. 1A/B/C/D) to the fan side (see pic 2) of the fan duct (see pic 1, 2A/B/C/D) using the included tapping screws (see pic 2, a/b/c/d).
2. Affix the system fan, with the fan duct attached, to the inside of the case (refer to pic 1, 3A/B/C/D).
3. Using a double sided tape, apply it to both sides of the heatsink (as depicted in pic 4)
4. Cap the heatsink side of the fan duct (see pic 2) to the HR-01 (see pic 5); From the heatsink side of the fan duct (as depicted in pic 2) there are four protruding points (see pic 3), with two on each side of the opening. Use these protruding points to connect the fan duct to the heatsink's hooking points, ie. the sixth gap (between the sixth fin and the seventh fin) from top/bottom (see pic 4).
5. Make sure the double sided tape (refer to pic 4) is firmly adhered in its position to ensure a complete hold between the fan duct and the heatsink.
6. Finally, install the fasteners (see pic 5, 4A/B/C/D) for the heatsink

Fan Duct Parts List For HR-01 (LGA-775)

Parts List	Quantity
Fan Duct	1
Double Sided Tape	2
Tapping Screws	5